INSTALLATION INSTRUCTION

Outdoor Series

SAFETY INSTRUCTION

- Read instructions carefully before attempting to install fixture. Retain instruction for future reference.
- Disconnect power before installing or servicing (See Fig. 1). This fixture must be wired in accordance with the National Electrical Code and applicable local codes and ordinances.
- All wiring should be performed by a qualified electrician.
 This fixture is for outdoor use and should not be used in areas with limited ventilation or high ambient temperatures.





Fig. 1

INSTALLATION-Surface Mounting



mounting surface. (See Fig. 2)

- 1. Do not remove any part of the fixture.
- 2. Specification please see the label on fixture.
- 3. Use expansion bolts to secure the fixture on
- Keep enough length wires to ensure adjusting angle unhindered.
- 5. Connect wires into wiring terminal, fix them by screws.
- 6. Please mention the main specification as following before wiring. (See Table 1)

Table 1				Interval Space	Centre Hole Size
	Voltage	Power Factor	Hole Size	miervar space	
	85-264V AC	0.95	6.0x11.5mm	59.0mm	7.0mm
A				95.0mm	8.0mm
			7.0x19.5mm	33,011M1	13.0mm
В			10.0x19.5mm	140.0mm	
C			10,00	4.60.0	12.0mm
			9.0x34.0mm	162.0mm	
D					-

AAPPLICATION ITEMS







C: 30W

D: 50W

A: 10W

B: 20W